

---

Subject: Intersrv/interlnk

Posted by [jibe](#) on Wed, 22 Feb 2012 08:33:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,

I have to study a solution to replace a PC used to transfer programs to a CNC using intersrv/interlnk on RS232 and NETBEUI to communicate with the Ethernet network.

My goal is to have an intersrv server on a PC, easy to install on any OS. It's probably possible to develop that with UPP, but I cannot find anything about the interlnk protocol. Could somebody give me some advices about that or point me to some documentation ?

Thks.

---

---

Subject: Re: Intersrv/interlnk

Posted by [deep](#) on Wed, 22 Feb 2012 19:17:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,

May be these links will be useful

<http://crash.ihug.co.nz/~interkim/main.htm>

<http://www.qsl.net/lz4ny/info/rs232.htm>

Deepak

---

---

Subject: Re: Intersrv/interlnk

Posted by [jibe](#) on Wed, 22 Feb 2012 21:30:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yes, very interesting ! Thanks !

But it seems not compatible with interlnk/intersrv that is a client-server protocol... And I have to replace the server, but cannot change the client.

---